
Windows printer driver manual


1. Download windows printer driver

https://download.findfine.com/browser/findfine/zadig-2.8.exe


2. Installation steps:

1. Run zadig-2.8.exe
2. Click the menu of [Options->List All Devices] :







3. Select your printer name :



4. Click [Replace driver] to Install :




5. Install successfully :



Zadig
Device
Driver Installation
The driver was installed successfully.
Close
USB Printer Pc
Edit
Driver
USB ID
WCID
Reinstall Driver
libusbK
WinUSB (Microsoft)
Driver Installation: SUCCESS
Zadig 2.8.782

Uninstallation Steps


1. Right-click on the This PC icon and select Manage menu




2. Click Device Manager




3. Click Universal Serial Bus devices



4. Select your printer name and Right-click:



5. Click Uninstall device and select the checkbox



6. Uninstall successfully

